

Change from Release Trigger to Pull Trigger

January 31, 2006

Remove the batteries.



Now, with the batteries out of the box and the trigger switch plugged into the red box, press and hold the switch button for about 30 seconds. This process discharges a capacitor through the trigger switch. You may now put the batteries back into the box (remember the big flat side faces the spring) and slide the cover back on. You may now test it by pressing the switch button one time and see if the red light blinks on.

The End